

SPACETABLES

Care & Maintenance

Periodic maintenance is necessary to insure long-term durability and customer satisfaction.

To prevent personal injury, furniture must be inspected regularly for loose screws, cracked glides and casters or broken welds, cracked laminate, wood splinters and general instability. Furniture that is damaged or appears to be unstable must be immediately removed from service and replaced or repaired using the factory authorized parts and methods. Contact Space Tables Service Department for assistance and further instructions.

Composite:

Use a solution of detergent mixed with warm water and nonabrasive cloth or sponge, wipe table top off, rinse and dry thoroughly. You may need to use a little elbow grease on tougher stains. Always clean spills immediately or staining may occur. To remove tougher stains use an automotive rubbing compound and follow the directions.

Laminates:

Wipe surface with a damp cloth using soap or liquid detergent. Remove stubborn stains with a damp paste of baking soda. Leave on for 1 minute, then blot away. Abrasive cleaners should not be used. Acid based products spilled on the surface should be wiped off immediately and then rinsed with water.

SPACEdge, Vinyl Edge & DesignEdge

Use a liquid detergent suitable for cleaning vinyl. After cleaning, wipe the surface with a cloth dampened with warm water.

Wood Finish:

Coat wood with a hard paste wax every three to four months during the first year of use. After the first year, application can be less frequent. To clean, use liquid cleaner-wax polish combination. Do not use abrasive household solvents. Water spills on the surface should be wiped off immediately.

Bases/Legs:

Clean with solution of detergent mixed with water using a nonabrasive cloth or sponge wipe external parts then rinse, and dry thoroughly. Take care not to allow mops and floor cleaners to hit legs and bases as they may nick or scratch finish and will expose raw steel which could cause rusting.

Caster maintenance:

Periodically check casters to make sure they are secure. The casters are not intended to be moved over long distances. Care should be taken when going over uneven surfaces.

Base Finish Maintenance:

Chrome protectant can be used on chrome legs. Black Wrinkle nicks and scratches can be touched up with black matte Rustoleum paint.

Special Tips:

Do not use a sanitizing agent before thoroughly cleaning with detergent, rinsing with water and drying thoroughly or damage will occur. Do not use any abrasive material or damage will occur.

Always use a heat shield, hot pad, or trivet when placing a hot pan on table top. Always use a cutting board.

Knives will damage surface. Always clean spills immediately or staining may occur.

Always rinse surfaces of bases after cleaning. Failure to rinse after cleaning is the greatest cause of surface damage. If even small amounts of cleaning solution remains on the surface, moisture can reactivate the cleaning solution and result in etched scars.

Space Tables, Inc. 11511 95th Avenue N. Maple Grove, MN 55369 United States
info@spacetables.com 800.328.2580 www.spacetables.com

